

USER MANUAL FOR NEW MODULE + SWITCHES (WITHOUT DISPLAY)

PIN CODE: 1234

1. To pair with your phone, you should active manual search mode.
2. Before clearing all the paired phones, you should disconnect the bluetooth firstly.
3. Please be noted that we haven't designed any ignition voice for the pairing mode & the "clear all paired phones" mode. (It will be enhanced later on.)
4. Before removing the display or changing switches, be sure to turn the ACC power off firstly, in order to protect the product itself.

KEYPAD	2-BUTTONS	3-BUTTONS
PAIRING	Press and hold the ANSWER key for 5 seconds	Press and hold the ANSWER key for 5 seconds
MEMORY ERASE/CLEAR ALL PAIRED PHONES	Press and hold the END key for 5 seconds	Press and hold the DOWN key for 5 seconds. The system will beep 2 times through the speaker.
MANUAL SEARCH	Press and hold the ANSWER key	Press and hold the ANSWER key
DISCONNECT BLUETOOTH	Press and hold the END key for 2 seconds	Press and hold the DOWN key for 2 seconds
REDIAL LAST NUMBER	Press and hold the ANSWER key for 2 seconds	Press and hold the ANSWER key for 2 seconds
VOICE DIALING	Press and hold the ANSWER key	Press and hold the ANSWER key
ENDING A CALL	Press and hold the END key for 2 seconds	Press and hold the ANSWER key
IGNORE CALL	Press and hold the END key	Press and hold the ANSWER key for 2 seconds
ANSWER CALL	Press and hold the ANSWER key	Press and hold the ANSWER key
ADJUSTING VOLUME	Press and hold the ANSWER or END key to raise or lower the volume, each press raises or lowers the volume by 1 level.	Press and hold the UP key or DOWN key to raise or lower the volume, each press raises or lowers the volume by 1 level.
MUTE THE BLUETOOTH MICROPHONE	N/A	Press and hold the DOWN key for 2 seconds
TRANSFER CALL	Press and hold the ANSWER key for 2 seconds	Press and hold the UP key for 2 seconds